



**MS700I/860I/6720 SETUP
GILBARCO G-SITE (C-2/486)**




METROLOGIC INSTRUMENTS
1(800) ID-METRO

**MS700I/860I/6720 SETUP
ENTER PROGRAM MODE**




Page 1

**MS700I/860I/6720 SETUP
RECALL DEFAULTS**



Page 2

**MS700I/860I/6720 SETUP
PARITY = EVEN**




Page 3

**MS700I/860I/6720 SETUP
ENABLE MECCA**



Page 4

**MS700I/860I/6720 SETUP
DISABLE LINE FEED**



Page 5

MS700I/860I/6720 SETUP

ENABLE UPC PREFIX



Page 6

MS700I/860I/6720 SETUP

ENABLE 2400 BAUD



Page 7

MS700I/860I/6720 SETUP


TRANSMIT UPC-A CHECK DIGIT



Page 8

MS700I/860I/6720 SETUP

TRANSMIT UPC-E CHECK DIGIT



Page 9

MS700I/860I/6720 SETUP

DISABLE LEADING ZERO ON UPC-E



© Page 10

MS700I/860I/6720 SETUP

EXIT PROGRAM MODE



Page 11