




WAYNE DRESSER PLUS & NUCLEUS CONFIG FOR MS6720, MS860 & MS700I SCANNERS

Please scan the following barcodes in order:



ENTER/EXIT PROGRAM M



5.

POWER ENTIRE SYSTEM DOWN, WAIT 1 MINUTE, POWER BACK UP.

Please note:Special cable required:

MS6720 requires cable # 52-52330A

MS860 & MS700I require cable # 51-51615A

The scanner will NOT communicate with the register without the proper cable.